EC REP
Importer: REP Europe GmbH
Address: Prinzenallee 7, 4th floor, 40549 Duesseldorf, Germany
Email: info@rep-europe.de
Tel: 0049 155 60128437

UK REP
Importer: Intercert Global Ltd
Address: 85 Great Portland Street, First Floor, London, W1W 7LT
Email: info@intercertglobal.co.uk
Tel: +447410638838

MANUFACTURED FOR
Company: Shenzhen Jianchao Intelligent Technology Co., Ltd.
Address: 3th floor, Bldg.7, No.68 Hexiu West Road, Fuhai St., Baoan, 518000, Shenzhen, CN.

2-Year Warranty
support@wavytalk.com
+1972 467 4080


Made in China







WAVYTALK
BEAUTY



Sculpt Time
Microcurrent Beauty Device

USER MANUAL

F2210 Pro

Support

support@wavytalk.com
+1972 467 4080

AMAZON:
< Go to Your Orders on Amazon
< Filter by order date
< Find this purchase
< Get Product Support
< Get help from Seller

TIKTOK:
< Visit the Product Page
< Scroll to "About this shop"
< Click "Message" to contact the seller

Contact us if you have any question.

Contents

1. IMPORTANT....1
   1.1 Indications for use....1
   1.2 Intended user and environment....1
   1.3 Device description....1
2. WARNINGS AND PRECAUTIONS....1-3
   2.1 Warnings....1
   2.2 Precautions....2
   2.3 Adverse Reaction....2
   2.4 Contraindications....2
3. PRODUCT DESCRIPTION....3-4
   3.1 Component Names....3
   3.2 Product Package....3
   3.3 Specification....3
4. MODES AND FUNCTIONS....4-6
   4.1 Mode Overview....4
   4.2 Recommended Frequency of Use....5
   4.3 Memory Function....5
   4.4 Intensity Level Indicator....5
   4.5 Mute Setting....5
   4.6 Charging and Battery Indicator....5
5. SKIN TEST....6
6. HOW TO USE....6-8
   6.1 Operation....6
   6.2 Before Use....7
   6.3 Cleanse Mode....7
   6.4 Lift Mode & Infuse Mode & Renew Mode....7
   6.5 Refine Mode....8
   6.6 Cleaning and Storage....8
7. TROUBLE SHOOTING....9-10
8. THE SYMBOLS AND DESCRIPTION....11
9. WARRANTY....12
10. RECYCLING & ENVIRONMENTALLY FRIENDLY DISPOSAL....12
11. EMC STATEMENT....12

User Manual

1. IMPORTANT

1.1 Indications for use

Microcurrent Beauty Device is a hand-held device for over-the-counter aesthetic purposes.
(1) The Microcurrent: Indicated for facial skin stimulation.
(2) The LED: The red light is intended for the treatment of wrinkles and the blue light is intended for the treatment of the mild to moderate inflammatory acne.

1.2 Intended user and environment

The device is portable and intended for use in a home environment for cosmetic purposes. It is suitable for adults with facial wrinkles or mild to moderate inflammatory acne.

1.3 Device description

The device is portable, non-sterile, and reusable, and is intended for aesthetic use. The device is powered by an internal rechargeable lithium battery, which can be charged using an external charger and a Type-C charging cable. The device cannot be used while charging.

2. WARNINGS AND PRECAUTIONS

2.1 Warnings

- Electrode wear or aging, such as wear of the electroplated layer, may cause skin irritation or allergic reactions because the underlying surface may become exposed and come into contact with the skin. Loose electrodes may result in no microcurrent output from the device. If any of the above conditions occur, please stop using the device. For any other issues, please contact Customer Service.
- DO NOT use this device for any purpose other than those specified in this manual.
- DO NOT expose this product to water or humid environments.
- DO NOT use this product while driving or walking.
- DO NOT look directly at the LED light source while the device is operating. Prolonged exposure to the LED light source may cause eye damage.
- DO NOT use high-voltage equipment near this product.
- DO NOT place naked flame sources, such as lit candles, on the device.
- DO NOT use the device for longer than the treatment time specified in Section 4.2. Prolonged use may cause low-temperature burns or other unknown adverse reactions. The effects of long-term repetitive stimulation have not been fully studied and remain unclear.
- DO NOT use the device if you are taking any medication known to cause photosensitivity.
- DO NOT use this device if you are currently undergoing, or have undergone within the past 2 months, any skin-related treatment, cosmetic procedure, or hair-loss treatment, including but not limited to facial surgery, eyelid surgery, thread lifts, laser resurfacing, medium or deep chemical peels, dermabrasion, RF microneedling, facial fat grafting, facial liposuction, or hair transplantation. Please consult your physician before use.
- Electrical stimulation should not be applied to the surface of the head or across the head. It should also not be applied directly over the eyes or mouth, on the front of the neck, especially over the carotid sinus, or on or across the chest, upper back, or heart area.
- When using this device on the neck, do not apply it to the thyroid area. Users with thyroid disorders must consult a physician before use.
- Application of electrodes near the thorax may increase the risk of ventricular fibrillation.
- DO NOT use this device on mucous membranes, including inside the mouth. Do not apply this device directly to the ears.
- DO NOT disassemble this device without authorization. Unauthorized modification of this device is strictly prohibited, as it may compromise safety compliance.
- DO NOT attempt to repair this device by yourself. Repairs should only be performed by qualified personnel designated by the manufacturer.
- DO NOT use this device in environments with strong electromagnetic interference.
- DO NOT splash liquids onto this device, as this may cause damage.
- DO NOT drop this device from a height.
- DO NOT allow infants or children under 18 years of age to use this product. Keep the device and its accessories out of reach of children. Children should be supervised to ensure that they do not play with the device, to avoid the risk of fire or burns.

- If necessary, contact the manufacturer or its representative for assistance with the installation, use, or maintenance of the device, or to report any unexpected operation or event.
- After the device has been removed from an environment at the minimum or maximum storage temperature, allow it to remain at room temperature for 4 hours before use.
- DO NOT place this product in direct sunlight or expose it to ultraviolet light for an extended period, as this may severely damage the product.
- DO NOT leave the device unattended while it is powered on, as this may cause fire or burns.
- This device is not intended for use by persons with reduced physical, sensory, or mental capabilities, or who lack experience and knowledge, unless they have been supervised or instructed on the proper use of the device, to avoid the risk of fire or burns.
- Water and electricity are a dangerous combination. To avoid the risk of electric shock, do not use this device in humid or wet environments, and do not allow water to enter the device.
- Avoid severe impacts or vibrations, as they may damage the device.
- Simultaneous use of high-frequency surgical equipment and the electrodes may cause burns at the electrode sites or damage to the electrodes.
- Operation in close proximity (e.g. 1 m) to a shortwave or microwave therapy equipment may produce instability in the stimulator output.
- To ensure device safety, do not use chargers of unknown origin or poor quality. The maximum output power of the charger must not exceed 30 W. Use an adapter that complies with IEC 60601-1 for charging. Input: 100–240 VAC; Output: DC 5 V, 1 A.

2.2 Precautions

- Use of this product is not recommended if you have a weakened immune system.
- Those with serious medical conditions or that are currently undergoing treatment should consult a physician before use.
- Regardless of the product used, your skin condition may temporarily change due to seasonal changes and external factors. In addition, internal factors such as alcohol consumption or stress may also affect your skin condition. If your skin condition worsens, stop using the device. Use the device again only after your skin condition has returned to normal or after consulting a physician.
- Before use, remove any precious metal items, such as jewelry, that may come into contact with the device.
- If the device overheats and causes discomfort during use, wait until the device has cooled down before continuing the treatment.
- The device can be used at home without professional assistance.

2.3 Adverse Reaction

- Skin irritation, such as redness or tingling, may occur during use depending on your individual skin type. If the irritation persists, consult a physician.
- Some users may experience skin irritation or hypersensitivity due to electrical stimulation or the conductive medium, such as conductive gel. This irritation can usually be reduced by using an alternative conductive medium.
- Skin irritation and burns beneath the electrodes have been reported with the use of other powered muscle stimulators. If you experience skin irritation or burning, discontinue use immediately.
- If you experience a persistent headache and/or other persistent pain during or after use of this device, discontinue use immediately and consult a physician.

2.4 Contraindications


- Do not use this device if you have a history of epilepsy or seizures.
- Do not use this device if you have recently undergone facial surgery or any other surgical procedure. Consult a physician before use.
- Do not use this product if you have an implanted electronic device, such as a defibrillator, neurostimulator, pacemaker, or ECG monitor. If you use a wearable medical device, such as an insulin pump, consult a physician before use.
- Do not use this device if you have any active cancer, or on or over any suspicious or cancerous lesions in the treatment area. Consult a physician before use.
- Do not use the device on skin with active acne, pus, or severe sensitivity. Resume use only after the skin condition has stabilized.
- Do not use this device if you have a photosensitive disorder, such as sun allergy.

- Do not use this device if you are pregnant.

Note: The above are only some of the known contraindications. Before using this product, it is recommended to consult a physician to determine whether it is suitable for you. For other precautions and operating instructions, please refer to the latest professional medical literature.

3. PRODUCT DESCRIPTION

3.1 Component Names



1. Level Button
2. Power/Mode Button
3. Intensity Level/Mode Indicator
4. Battery Indicator
5. Refine Head
6. Y-Shaped Head
7. Teardrop-Shaped Head
8. Cotton Pad Clip
9. Charging Port (Back of Main Unit)
10. Stand Dock

3.2 Product Package


Main Unit*1
Teardrop-Shaped Head*1
Y-Shaped Head*1
Cotton Pad Clip*1
Stand Dock*1
USB Charging Cable*1
Storage Pouch*1
Cotton Pad*1
User Manual*1
Quick Guide*1

3.3 Specification

Basic Information	
Product Name	Microcurrent Beauty Device
Model	F2210 Pro
Treatment Area	Face
Main Unit Dimensions[L×W×H]	38*42*160mm
Teardrop-Shaped Head Area	13.23 cm^2
Y-Shaped Head Area	21.04 cm^2
Refine Head Area	8.41 cm^2
Stand Dock Dimensions	70*80*75mm
Net Weight (Main Unit+2 Heads+Stand Dock)	310g
Power	
Input	DC 5V 1A
Battery	Li-ion rechargeable battery 3.7V, 900mAh
Charging Time	<120min
Operating Time	>35min
Working environment	
Temperature	5°C~30°C
Humidity	15%~75%
Atmosphere	86~106kPa
Storage environment	
Temperature	-10°C ~45°C
Humidity	15%~90%
Atmosphere	86~106kPa

4. MODES AND FUNCTIONS

4.1 Mode Overview

MODE	Benefits	Treatment Head
Cleanse	Help remove dirt, oil, and impurities from the skin and pores	
Lift	Help improve the appearance of skin firmness and support a more lifted-looking contour	
Infuse	Help skincare products absorb more effectively into the skin	
Renew	Help reduce the appearance of fine lines	
Refine	Help refine the appearance of pores and improve overall skin texture	

*Each mode operates for 5 minutes and will automatically power off when the session is complete.

4.2 Recommended Frequency of Use

MODE	Duration per use	FREQUENCY OF USE
Cleanse	5min	Once daily
Lift	5min	
Infuse	5min	
Renew	5min	2-3 times per week
Refine	5min	

***Do not use the device for more than 30 minutes per day.**


4.3 Memory Function

The device automatically retains the previously selected mode for the next use.

4.4 Intensity Level Indicator

Each mode has three intensity levels, indicated by three different light colors: white for Level 1, light blue for Level 2, and dark blue for Level 3.

The light position indicates the selected mode, and the color indicates the current level.



Tips:

*When using the device for the first time, start with the lowest setting.
*Use a lower intensity setting on sensitive areas, such as the area around the eyes.

4.5 Mute Setting


Press and hold the Level button for 5 seconds. One beep means sound prompts are muted. To restore sound prompts, press and hold the Level button for 5 seconds again. One beep means sound prompts are restored.


Note: Alarm sounds will not be muted.

4.6 Charging and Battery Indicator

4.6.1 Battery charging

Before using this product, please fully charge it:





- Connect the charging adaptor (100-240V~ 50/60HZ, 5V 1A) with the charging cable.
- Connect the charging cable to the charging port of the device unit.
- Connect the charging adapter to the power socket.
- The battery indicator blinks red during charging and stays solid green when fully charged.

Tips:

Before using the product, please fully charge the device, and **the device should not be used during charging.**

4.6.2 Sufficient battery


If the battery indicator stays on, then the device can be used normally.

4.6.3 Low battery alert

If while in use the battery indicator shows red, continuous flashes and the device beeps three times, please charge the device as soon as possible.

5. SKIN TEST

Before first use, perform a skin test to help prevent skin irritation or other skin concerns.
Follow the steps below:
Step 1: Clean the inner side of your arm and dry it with a towel or tissue.
Step 2: Apply an appropriate amount of skincare product to the treatment head.
Step 3: Turn on the device, select **Lift Mode**, and set it to **Level 1**.
Step4: Glide the device over your forearm for 3 minutes.



*If there is not enough skincare product during use, apply more as needed to ensure the treatment head glides smoothly over the skin.

* Keep the treatment head in full contact with the skin during use.


Note:

- Adverse reactions may include pain, itching, skin redness, swelling, or other discomfort in the treatment area.
- **Wait at least 6 hours after the test.** If the skin appears normal, you may proceed with your treatment.
- During use, a tingling sensation may occur due to skin sensitivity to the microcurrent. This is normal.


6. HOW TO USE

6.1 Operation

- **Power On/Off:** Press and hold the ⏻/Mode button for 2 seconds to power on/off.
- **Select a Mode:** Press the ⏻/Mode button briefly to select a mode.



- **Select an Intensity Level:** Press the Level button briefly to select an intensity level.



6.2 Before Use

Before use, thoroughly cleanse your face and pat it dry.

Attention: Do not use the device on the shaded areas shown below:



- Areas within the eye socket, such as the eyeballs and upper eyelids
- Throat or Adam's apple
- Thyroid area


Different betweent Y-shaped Head and Teardrop-Shaped Head:

*For **targeted jawline care**, the Y-Shaped Head is recommended.

*For **precise facial care**, such as around the eyes and nose, the Teardrop-Shaped Head is recommended.

6.3 Cleanse Mode

- **Usage Steps**





Step 1: Attach the teardrop-shaped head.
Step 2: Install the cotton pad. As shown in the figure, **secure the top of the cotto pad clip first, then secure the bottom.**
Step 3: Saturate a cotton pad with makeup remover or toner.
Step 4: Select Cleanse Mode.

6.4 Lift Mode & Infuse Mode & Renew Mode

- **Usage Steps**


Step 1: Select one of the treatment heads and attach it to the main device.
Step 2: Apply the appropriate skincare product. Please use a water-based skincare product to ensure the device glides smoothly.





- **Gliding Guide**

Path 1: Glide from the corner of the mouth (A) to the upper cheek area (B), then **hold for 2 seconds.**
Path 2: Glide from above the eyebrow (C) to the upper forehead (D), and **hold for 2 seconds.**




6.5 Refine Mode

- **Usage Steps**

Use on dry skin: After cleansing, be sure to use it on dry skin. **It won't properly transmit stimulation when used on wet skin. No skincare products are needed for this mode.**

- **Sweeping**

Gently place the **edge** of the treatment head against the skin. Gently sweep it with the **edge**.





6.6 Cleaning and Storage

- **Cleaning**

Do not rinse the treatment head or device body directly withh water.
After each use, clean the treatment head with a purified waterwipe or an alcohol pad.
Do not clean this product with alkaline cleaning agents or organic solvents, such as, thinner, gasoline, or nail polish remover.
After cleaning, visually inspect the device. If any residue remains, repeat the cleaning steps until it is visibly clean.

- **Storage**

Ensure that the device is powered off before storage.
Avoid storing the device in dusty, humid, or direct sunlight conditions.

7. TROUBLE SHOOTING

Problem	Possible Cause	Solution
Cannot power on.	Low battery.	Charge the device, then try turning it on again.
	The power button was not pressed long enough.	Press and hold the power button for 2 seconds.
	The device is charging.	The device cannot be used while charging. Please wait until charging is complete before using the device.
	Possible device malfunction.	Please contact customer support.
Cannot charge.	The wrong adapter is being used.	Please use a DC 5 V 1 A adapter for charging.
	Poor contact or loose connection.	Check that the device, power adapter, and wall outlet are securely connected.
	The outlet has no power.	Check that the outlet has power and is working properly.
	The charging cable may not be properly connected.	Please contact customer support.
Can only be used for a few minutes after being fully charged.	The treatment time for one mode has ended.	This device has an auto shut-off function and will automatically power off after 5 minutes of use.
	Possible battery life issue.	Please contact customer support.
Device feels warm.	The device may become slightly warm after use, which is normal.	Turn off the device and let it rest for at least 1 hour before using it again.
	The device becomes very hot after use, which may indicate a device malfunction.	Stop using the device and contact customer support.
A slight tingling or electric current sensation may occur when using the microcurrent stimulation mode.	This is normal. The device uses microcurrent technology to deliver gentle, low-level electrical stimulation to the skin.	If discomfort occurs, lower the intensity level and use less skincare product.
Strong stinging sensation from the current.	The intensity level is too high.	Use a lower intensity level.
	The treatment head is not in close contact with the skin.	Place the treatment head fully against the skin. (Except for Cleanse and Refine modes.)

Problem	Possible Cause	Solution
Current intensity is too low or no current sensation can be felt.	The intensity level is too low.	Use a higher intensity level. (Except for Cleanse mode.)
	Not enough skincare product was applied.	Apply more skincare product, or after cleansing, spray an appropriate amount of facial mist or toner on your face before use. (Except for Cleanse and Refine modes.)
	Current sensation is not obvious in some areas.	Different facial areas may have different levels of sensitivity to current, so it is normal for the current sensation to vary by area.
	Some areas have a curved surface, such as the forehead, so the treatment head may not be fully in contact with the skin.	Place the treatment head fully against the skin. (Except for Refine Mode.)
Heat sensation is too high.	The intensity level is too high.	Use a lower intensity level. (For Lift and Renew Modes only.)
When the Y-shaped head or teardrop-shaped head is not attached, the mode cannot be adjusted.	This is part of the product design and is not a malfunction. In this state, only Refine Mode can be used.	To use other modes, please attach the Y-shaped head or teardrop-shaped head.
When the Y-shaped head is attached, Cleanse Mode cannot be selected.	This is part of the product design and is not a malfunction. Cleanse Mode is only available with the teardrop-shaped head.	To use Cleanse Mode, please attach the teardrop-shaped head.
The device malfunctioned after being cleaned with water.	The device is not waterproof. Rinsing it with water may cause functional failure.	To clean the device, use a purified water wipe or an alcohol pad. Do not rinse the device directly with water.

8. THE SYMBOLS AND DESCRIPTION

Symbol	Meaning	Symbol	Meaning
LOT	Batch Code	SN	Serial number
	Refer to instruction manual/ booklet		Type BF Applied Part
	Class II equipment		Direct current
	Manufacturer		Manufacture Date
	General warning sign		“WEEE (Waste Electrical and Electronic Equipment)”. The waste products should be handled legally.
	Keep away from sunlight		Keep dry
	Fragile, handle with care	FCC	FCC certification
CE	CE mark	RoHS	RoHS “Restriction of Hazardous Substances”

9. WARRANTY

We grant a **2-year guarantee** on the product starting on the date of purchase. Within the guarantee period we will eliminate any defects in the appliance resulting from faults in materials or workmanship, free of charge either by repairing or replacing the complete appliance at our discretion.

This guarantee does not cover: damage due to improper use, abnormal wear and tear as well as defects that have a negligible effect on the value or operation of the appliance.

This guarantee extends to every country where this appliance is supplied by us or its appointed distributor. The guarantee becomes void if repairs are undertaken by unauthorized persons or if original parts are not used.

To obtain service within the guarantee period, hand in or send the complete appliance with your sales receipt to an authorized Customer Service Team. Support@wavytalk.com

10. RECYCLING & ENVIRONMENTALLY FRIENDLY DISPOSAL



In order to protect the environment, after the expiration of the products service life, it should not be discarded in the same way as domestic garbage; please recycle at a professional recycling center.
For further information on the recycling of this product, please consult your local municipality, processing service center, or the store where you purchased the product.
You can help protect the environment! Please remember to respect the local regulations, and hand in the non-working electrical equipment to an appropriate waste disposal center.

11. EMC STATEMENT

1) The device needs special precautions regarding EMC and need to be installed and put into service according to the EMC information provided in the accompanying document;
2) Portable and mobile RF communications equipment can affect the device.

Warning:

1) Don’t use the product near by active HF surgical equipment and the RF shielded room of an ME system for magnetic resonance imaging, where the intensity of EM disturbances is high.
2) Use of accessories, transducers and cables other than those specified or provided by the manufacturer of the device could result in increased electromagnetic emissions or decreased electromagnetic immunity of this equipment and result in improper operation.
3) Use of the device adjacent to or stacked with other equipment should be avoided because it could result in improper operation. If such use is necessary, this equipment and the other equipment should be observed to verify that they are operating normally.
4) Do not expose the device to the EM emitters, including but not limited to: radio-frequency identification(RFID) readers, security systems (e.g..metal detectors or electronic article surveillance(EAS)), wireless power transfer(WPT), and 5G cellular signals.
5) Portable RF communications equipment (including peripherals such as antenna cables and external antennas) should be used no closer than 30 cm (12 inches) to any part of the device, including cables specified by the manufacturer. Otherwise, degradation of the performance of this equipment could result.
6) When functions or performance are lost due to EM disturbances, user should shut down the device and then use it again after being away from the interference source.